



vehicle application list
version 1.0.0



easycheck



EOBD/OBDII Application

Make	From	Harness Required
Petrol vehicles	2000/2001	YTD950
Diesel vehicles	2004	YTD950

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
Alfa Romeo	145	94 - 00	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	146	94 - 00	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	147	00 - 07	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 5.7 ABS/ASR/TC, Bosch 8 ABS, Bosch 8 ASR, Bosch 8 VDC	YTD951 B1
Alfa Romeo	155	95 - 97	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	156	97 - 02	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	156 '02	02 - 05	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 5.7 ABS/ASR/TC	YTD958 or YTD951 B1
Alfa Romeo	159	05 -	TRW / Lucas ABS	YTD951 B1
Alfa Romeo	164	88 - 98	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	166	98 - 03	Bosch 5.3 ABS, Bosch 5.3 TC ABS, Bosch 5.7 VDC	YTD958 or YTD951 B1
Alfa Romeo	33	88 - 89	Bosch 5.3 ASR ABS	YTD958 or YTD951 B1
Alfa Romeo	GT	04 -	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 8 ABS, Bosch 8 VDC	YTD951 B1
Alfa Romeo	GTV	95 - 03	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	Spider	95 - 03	Bosch 5.3 ABS	YTD958 or YTD951 B1
Audi	80/Cabrio/Coupe/Quattro	94 - 96	KWP1281	YTD952
Audi	A2	00 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	96 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	04 -	CAN	YTD950
Audi	A4	95 - 04	KWP1281/KW2000	YTD951 A1
Audi	A4	04 -	CAN	YTD950
Audi	S4	95 - 04	KWP1281/KW2000	YTD951 A1
Audi	S4	04 -	CAN	YTD950
Audi	A6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	A6	04 -	CAN	YTD950
Audi	S6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S6	04 -	CAN	YTD950
Audi	Allroad Quattro	01 - 04	KWP1281/KW2000	YTD951 A1
Audi	Q7	06 -	CAN	YTD950
Audi	A8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	A8	04 -	CAN	YTD950
Audi	S8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	S8	04 -	CAN	YTD950
Audi	TT	98 - 07	KWP1281/KW2000	YTD951 A1
Audi	TT	07 -	CAN	YTD950
Audi	100	94 - 97	KWP1281/KW2000	YTD952
BMW	1 Series (E81/E87)	04 - 03/07	Teves MK 60E, Teves MK 60E5	YTD960
BMW	3 Series (E36)	90 - 98	ABS uC 3 Channel, ABS ASC ITT, ABS/ASC 5, Bosch ABS DSC3, Teves MK 20	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E46)	98 - 05	ABS/DSC 5.7, Teves MK 20, Teves MK 60, Teves DSC III MK 60	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	Bosch ABS DSCS8 Plus, Teves MK 60E, Teves MK 60E5	YTD960
BMW	5 Series (E39)	96 - 04	ABS/ASC 5, ABS/ASC 5.7, ABS/DSC 5.7	YTD957 or YTD951 A6 / YTD960
BMW	5 Series (E60/E61)	04 - 03/07	Bosch ABS DSC8, Bosch ABS DSCS8 Plus, Teves MK 60E5	YTD960
BMW	6 Series (E63/E64)	05 - 03/07	Bosch ABS DSC8, Bosch ABS DSCS8 Plus, Teves MK 60E5	YTD960
BMW	7 Series (E38)	94 - 02	ABS 5, ABS/ASC 5, BOSCH ABS DSC3	YTD957 or YTD951 A6 / YTD960
BMW	7 Series (E65)	02 - 03/07	ABS/DSC5.7	YTD960
BMW	8 Series (E31)	90 - 99	ABS 5, ABS/ASC 5, BOSCH ABS DSC3	YTD957

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
BMW	X3 (E83)	03 -	DSC 8 X-Drive	YTD951 A6 / YTD960
BMW	X5 (E53)	00 -	ABS/DSC 5.7, DSC 8 X-Drive	YTD951 A6 / YTD960
BMW	Z3 (E36)	96 - 03	Bosch ABS DSC3, Teves MK 20	YTD957 or YTD951 A6 / YTD960
BMW	Z4 (E85)	03 -	Teves DSC III MK 60, DSC MK60E5	YTD951 A6
BMW	Z8 (E52)	00 - 03	ABS/DSC 5.7	YTD957 or YTD951 A6 / YTD960
Citroen	Berlingo	96 - 04	Bosch 5.0 / 5.3 ABS	YTD953 or YTD951 J6
Citroen	C1	05 - 05	Bosch 8 ESP	YTD953 or YTD951 J6
Citroen	C2	03 - 05	Teves MK60 / MK70	YTD953 or YTD951 J6
Citroen	C3	02 - 05	Bosch 5.7 ESP / Teves MK60	YTD953 or YTD951 J6
Citroen	C4	04 - 05	Bosch 5.7 ESP / Teves MK60	YTD953 or YTD951 J6
Citroen	C5	00 - 05	Bosch 5.7 ESP / Teves MK60	YTD953 or YTD951 J6
Citroen	C8	02 - 05	Bosch 5.7 ESP / Teves MK60	YTD953 or YTD951 J6
Citroen	Dispatch/Jumpy	95 - 02	Bosch 5.3 ABS	YTD953 or YTD951 J6
Citroen	Evasion	97 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Citroen	Relay/Jumper	97 - 02	Bosch 5.3 ABS	YTD953 or YTD951 J6
Citroen	Saxo	98 - 03	Teves MK 20E/IE ABS / Teves 4-GI (ITT 04-GI) ABS	YTD953 or YTD951 J6
Citroen	Synergie	97 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Citroen	Xantia	98 - 02	Bosch 5.3 ABS / Teves MK 20E/IE ABS	YTD953 or YTD951 J6
Citroen	XM	96 - 01	Teves MK 20E/IE ABS	YTD953 or YTD951 J6
Citroen	Xsara	97 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Citroen	Xsara Picasso	99 - 03	Bosch 5.3 ABS / Bosch 5.7 ESP	YTD953 or YTD951 J6
Fiat	Barchetta	96 - 00	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Coupe	96 - 02	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Croma	93 - 96	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Croma '05	05 -	TRW / Lucas ABS	YTD951 B1
Fiat	Ducato	94 - 02	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Ducato RST	01 -	Bosch 5.3 ABS, Bosch 5.3 ASR ABS	YTD951 B1
Fiat	Idea	01 -	Bosch 5.3 ABS, Bosch 5.3 ASR ABS, Bosch 8 ABS, Bosch 8 VDC	YTD951 B1
Fiat	Marea/Weekend	96 - 99	Lucas ABS	YTD958 or YTD951 B1
Fiat	Multipla	98 - 01	Bosch 5.3 ABS, Bosch 5.7 VDC ABS	YTD958 or YTD951 B1
Fiat	Multipla '02	02 -	Bosch 5.3 ABS, Bosch 5.7 VDC ABS	YTD951 B1
Fiat	Palio	97 - 01	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Palio RST	01 - 02	Bosch 5.3 ABS	YTD951 B1
Fiat	Palio RST2	02 -	Bosch 5.3 ABS	YTD951 B1
Fiat	Panda 03	03 -	Bosch 8 ABS, Bosch 8 VDC ABS	YTD951 B1
Fiat	Punto	93 - 99	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Punto '99	99 - 03	Bosch 5.3 ABS, Bosch 5.3 TC ABS	YTD958 or YTD951 B1
Fiat	Punto '03	03 - 05	Bosch 5.3 ABS, Bosch 8 ABS, Bosch 8 VDC ABS	YTD958 or YTD951 B1
Fiat	Scudo	97 - 01	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Seicento	98 - 00	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Stilo	01 -	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 5.7 ABS/ASR/TC, Bosch 8 ABS, Bosch 8 VDC	YTD951 B1
Fiat	Ulysse	97 - 02	Bosch 5.3 ABS	YTD951 B1
Fiat	Ulysse '02	02 - 05	Bosch 5.7 ABS	YTD951 B1
Ford	Cougar	99 - 02	ABS	YTD950 or YTD960

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
Ford	Crown Victoria	95 - 07	ABS	YTD950 or YTD960
Ford	Escort	95 - 02	ABS	YTD950 or YTD960
Ford	Excursion	00 -	ABS	YTD950 or YTD960
Ford	Expedition	97 -	ABS	YTD950 or YTD960
Ford	Explorer	96 -	ABS	YTD950 or YTD960
Ford	E-Series	97 - 08	ABS	YTD950 or YTD960
Ford	F-250 Light Duty	97 - 02	ABS	YTD950 or YTD960
Ford	Fiesta	96 -	ABS	YTD950 or YTD960
Ford	Focus	99 - 06	ABS	YTD950 or YTD960
Ford	Focus C-MAX	02 -	ABS	YTD950 or YTD960
Ford	Fusion	02 -	ABS	YTD950 or YTD960
Ford	F-Series Super Duty	97 -	ABS	YTD950 or YTD960
Ford	Galaxy	00 - 06	ABS	YTD950 or YTD960
Ford	Granada/Scorpio	94 - 98	ABS	YTD950 or YTD960
Ford	GT	05 - 06	ABS	YTD950 or YTD960
Ford	Ka	96 - 06	ABS	YTD950 or YTD960
Ford	Street Ka	03 -	ABS	YTD950 or YTD960
Ford	Maverick	01 - 04	ABS	YTD950 or YTD960
Ford	Maverick 05	05 -	ABS	YTD950 or YTD960
Ford	Mondeo III	95 - 06	ABS	YTD950 or YTD960
Ford	Puma	97 - 01	ABS	YTD950 or YTD960
Ford	Ranger	99 - 06	ABS	YTD950 or YTD960
Ford	Transit	00 - 06	ABS	YTD950 or YTD960
Ford	Transit / Torneo Connect	02 -	ABS	YTD950 or YTD960
Ford	WindStar	96 - 04	ABS	YTD950 or YTD960
GM	Agila	00 - 08	Agila ABS	YTD951 A2
GM	Astra-F	92 - 97	Bosch 2E	YTD951 J2
GM	Astra-G	98 - 04	Bosch 5.3/5.4TC, ESP	YTD951 A2
GM	Astra-H	04 -	Astra-H ABS/TC/ESP	YTD950 or YTD960
GM	Calibra	90 - 97	Bosch 2E	YTD951 J2
GM	Combo	02 - 06	Bosch5.3/5.4TC, Bosch 8	YTD951 A2/J2
GM	Corsa-B	97 - 01	Bosch 5.3	YTD951 J2
GM	Corsa-C	01 -06	Bosch5.3/5.4TC, Bosch 8	YTD951 A2/J2
GM	Corsa-D	06 -	Corsa-D ABS/TC/ESP	YTD950 or YTD960
GM	Frontera-A	95 - 98	Bosch 415	YTD951 J2
GM	Movano	04 - 06	ABS 430	YTD951 A2
GM	Meriva	03 - 08	Bosch 8	YTD951 A2
GM	Omega-B	94 - 03	Bosch 2SH, Bosch 5.3/5.4TC, ESP	YTD951 A2/J2
GM	Signum	01 -	EBC430 ABS/TC/ESP	YTD950 or YTD960
GM	Speedster / VX220	01 - 06	KH430	YTD951 J2
GM	Tigra-A	95 - 00	ABS 4/4F, Bosch 5.3	YTD951 J2
GM	Tigra-B	05 - 08	Bosch 8	YTD951 A2
GM	Vectra-B	96 - 01	Bosch 415, Bosch 5 TC, KH430, Bosch5.3/5.4TC	YTD951 J2
GM	Vectra-C	01 -	EBC430 ABS/TC/ESP	YTD950 or YTD960
GM	Vivaro	01 - 06	ABS 430	YTD951 A2

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
GM	Zafira-A	99 - 05	Bosch 5.3/5.4TC, Bosch 8	YTD951 A2
GM	Zafira-B	05 -	Zafira-B ABS/TC/ESP	YTD950 or YTD960
Lancia	Dedra	94 - 99	Bosch 5.3 ABS	YTD958 or YTD951 B1
Lancia	Delta	96 - 00	Bosch 5.3 ABS	YTD958 or YTD951 B1
Lancia	Kappa	94 - 01	Bosch 5.3 ABS	YTD958 or YTD951 B1
Lancia	Lybra	99 - 06	Bosch 5.3 ABS, Bosch 5.3 ASR ABS, TRW Lucas ESP ABS	YTD958 or YTD951 B1
Lancia	Musa	04 - 06	Bosch 8 ABS, Bosch 8 VDC ABS	YTD951 B1
Lancia	Phedra	02 - 06	Bosch 5.7 ABS, Bosch 5.7 ESP	YTD951 B1
Lancia	Thesis	02 - 06	TRW / Lucas ABS	YTD951 B1
Lancia	Y	96 - 03	Bosch 5.3 ABS	YTD958 or YTD951 B1
Lancia	Ypsilon	03 - 06	TRW / Lucas ABC, TRW / Lucas ESP ABS	YTD951 B1
Lancia	Z	96 - 02	Bosch 5.3 ABS	YTD958 or YTD951 B1
Land Rover	Defender	99 - 03	Wabco D	YTD951 A1
Land Rover	Freelander	98 - 01	Wabco D	YTD951 A1
Land Rover	Freelander	01 - 06	ABS Mk25	YTD951 K2
Land Rover	Discovery II	99 - 04	Wabco D	YTD951 A1
Land Rover	Range Rover	99 - 03	Wabco D	YTD951 A1
Mercedes	A Class (W168)	98 - 03	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	A Class (W169)	04 -	ESP 169	YTD950
Mercedes	B Class (W245)	05 -	ESP 169	YTD950
Mercedes	C Class (W202)	93 - 01	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	C Class (W203)	00 - 09/03	ESP Mk25	YTD951 G2
Mercedes	C Class (W203)	09/03 - 07	ESP Mk25 (CAN)	YTD950
Mercedes	CL Class (W215)	99 - 06	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	CLK (W208)	98 - 02	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	CLK (W209)	02 - 04/04	ESP Mk25	YTD951 G2
Mercedes	CLK (W209)	04/04 - 02	ESP Mk25 (CAN)	YTD950
Mercedes	CLS (W219)	04 -	SBC/ESP	YTD950
Mercedes	CLS (W219)	04 -	SBC (CAN)	YTD950
Mercedes	E Class (W210)	95 - 03	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	E Class (W211)	02 -	EHB FSG	YTD951 G2
Mercedes	E Class (W211)	02 -	Sensotronic BC	YTD951 G2
Mercedes	E Class (W211)	02 -	SBC/ESP	YTD950
Mercedes	E Class (W211)	02 -	SBC (CAN)	YTD950
Mercedes	G Class (W461)	98 - 02	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	G Class (W463)	98 -	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	M Class (W163)	95 - 03	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	M Class (W164)	05 -	ESP164	YTD950
Mercedes	R Class (251)	05 -	ESP164	YTD950
Mercedes	S Class (W140)	91 - 08	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	S Class (W220)	98 - 05	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	S Class (W221)	05 -	ABR	YTD950
Mercedes	SL (R129)	93 - 03	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	SL (R230)	03 - 06	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	SL (R230)	03 - 06	EHB FSG	YTD951 G2 and/or YTD956

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
Mercedes	SL (R230)	03 - 06	Sensotronic BC	YTD951 G2 and/or YTD956
Mercedes	SL (R230)	03 - 06	SBC/ESP	YTD950
Mercedes	SL (R230)	03 - 06	SBC (CAN)	YTD950
Mercedes	SLK (R170)	91 - 04	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	SLK (R171)	04 -	ESP Mk25 (CAN)	YTD950
Mercedes	SLR (199)	04 -	EHB FSG	YTD951 G2
Mercedes	SLR (199)	04 -	Sensotronic BC	YTD951 G2
Mercedes	Sprinter (W901 / W902 / W903 / W904)	95 - 02	ABS / ASR / ETS/ ESP	YTD951 G2 and/or YTD955
*For BAS (if present) try switch positions G2, D2, F2				
MINI	MINI (R50 / R53)	00 - 07	Teves MK 60, Teves DSC III MK 60	YTD951 A6
Peugeot	1007	04 - 05	Teves MK60	YTD953 or YTD951 J6
Peugeot	106	96 - 04	Teves 4-GI (ITT 04-GI) ABS / Teves MK 20E/IE ABS	YTD953 or YTD951 J6
Peugeot	107	05 - 05	Bosch 8 ESP	YTD953 or YTD951 J6
Peugeot	206	98 - 05	Teves MK 20E/IE ABS / Teves MK60 / Teves MK70	YTD953 or YTD951 J6
Peugeot	306	93 - 02	Bosch 5.0 ABS / Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	307	01 - 07	Bosch 5.3 ABS / Bosch 5.7 ESP / Bosch 8 ESP	YTD953 or YTD951 J6
Peugeot	406	95 - 03	Bosch 5.0 ABS / Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	605	96 - 00	Bosch 5.0 ABS / Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	607	00 - 03	Bosch 5.3 ABS / Bosch 5.7 ESP	YTD953 or YTD951 J6
Peugeot	806	97 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	807	02 - 05	Bosch 5.7 ESP	YTD953 or YTD951 J6
Peugeot	Boxer	97 - 01	Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	Expert	97 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	Partner / Ranch	96 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Renault	Clio		Bosch 5.0 / Bosch 5.3/5.3T	YTD951 A1
Renault	Megane	98-03	Bosch 5.0 / Bosch 5.3/5.3T	YTD951 A1
Renault	Megane II	03 -	ABS 8 v3.0	YTD950
Renault	Kangoo	01 -	Bosch 8 ESP	YTD951 A1
Renault	Laguna	98 - 01	Bosch 5.3/5.3T / Teves MK 20	YTD951 A1
Renault	Laguna II	99-03	Teves MK 60	YTD951 A1
Renault	Scenic	98-03	Bosch 5.0 / Bosch 5.3/5.3T	YTD951 A1
Renault	Scenic II	03 -	ABS 8 v3.0	YTD950
Seat	Alhambra	96 -	KWP1281 / KW2000	YTD951 A1
Seat	Altea	04 -	CAN	YTD950
Seat	Arosa	97 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Cordoba	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Ibiza	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Leon	00 - 04	KWP1281 / KW2000	YTD951 A1
Seat	Leon	04 -	CAN	YTD950
Seat	Toledo	92 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Toledo III	04 -	CAN	YTD950
Skoda	Fabia	00 - 07	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Fabia II	07 -	CAN	YTD950
Skoda	Octavia	96 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Octavia II	04 -	CAN	YTD950

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
Skoda	Superb	02 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Beetle	99 -	KWP1281 / KW2000	YTD951 A1
VW	Bora	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Bora	05 -	CAN	YTD950
VW	Cabrio	95 - 02	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	92 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	05 -	CAN	YTD950
VW	Corrado	91 - 95	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	EOS	05 -	CAN	YTD950
VW	Eurovan	99 - 03	KWP1281/KW2000	YTD950
VW	Golf/GTI	92 - 03	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Golf/GTI	03 -	CAN	YTD950
VW	Golf Plus	05 -	CAN	YTD950
VW	Jetta	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Jetta	05 -	CAN	YTD950
VW	Lupo	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	94 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	05 -	CAN	YTD950
VW	Phaeton	03 -	KWP1281 / KW2000	YTD951 A1
VW	Polo	98 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Touareg	03 - 06	KWP1281 / KW2000	YTD951 A1
VW	Touareg	07 -	CAN	YTD950
VW	Touran	03 -	CAN	YTD950
VW	Sharan	95 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle T5	04 -	CAN	YTD950
VW	Vento	92 - 98	KWP1281 / KW2000	YTD950

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Alfa Romeo	145	94 - 98	TRW2	YTD958 or YTD951 D1
Alfa Romeo	145	94 - 00	TRW MY97	YTD958 or YTD951 D1
Alfa Romeo	146	94 - 98	TRW2	YTD958 or YTD951 D1
Alfa Romeo	146	95 - 00	TRW MY97	YTD958 or YTD951 D1
Alfa Romeo	147	00 - 04	Allied MY97	YTD951 D1
Alfa Romeo	147	00 - 07	Siemens MY99	YTD951 D1
Alfa Romeo	156	97 - 02	Allied MY97, Allied Signal, Allied Signal 2	YTD958 or YTD951 D1
Alfa Romeo	156 '02	02 - 05	Siemens MY99	YTD951 D1
Alfa Romeo	159	05 -	TRW MY03	YTD950 or YTD959
Alfa Romeo	166	98 - 03	TRW MY97, TRW MY99	YTD958 or YTD951 D1
Alfa Romeo	GT	04 -	Siemens MY99	YTD951 D1
Alfa Romeo	GTV	95 - 98	TRW2 Airbag w/pretensioners	YTD958 or YTD951 D1
Alfa Romeo	GTV	97 - 03	TRW MY97	YTD958 or YTD951 D1
Alfa Romeo	Spider	95 - 98	TRW2 Airbag w/pretensioners	YTD958 or YTD951 D1
Alfa Romeo	Spider	97 - 03	TRW MY97	YTD958 or YTD951 D1
Audi	80/Cabrio/Coupe/Quattro	94 - 96	KWP1281	YTD952
Audi	A2	00 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	96 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	04 -	CAN	YTD950
Audi	A4	95 - 04	KWP1281/KW2000	YTD951 A1
Audi	A4	04 -	CAN	YTD950
Audi	S4	95 - 04	KWP1281/KW2000	YTD952
Audi	S4	04 -	CAN	YTD950
Audi	A6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	A6	04 -	CAN	YTD950
Audi	S6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S6	04 -	CAN	YTD950
Audi	Allroad Quattro	01 - 04	KWP1281/KW2000	YTD951 A1
Audi	Q7	06 -	CAN	YTD950
Audi	A8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	A8	04 -	CAN	YTD950
Audi	S8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	S8	04 -	CAN	YTD950
Audi	TT	98 - 07	KWP1281/KW2000	YTD951 A1
Audi	TT	07 -	CAN	YTD950
Audi	100	94 - 97	KWP1281/KW2000	YTD952
BMW	1 Series (E81/E87)	04 - 03/07	MRS5	YTD960
BMW	3 Series (E30)	91 - 93	Driver Airbag (5WK4 060)	YTD957
BMW	3 Series (E36)	90 - 98	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E36)	91 - 93	Driver Airbag (5WK4 060)	YTD957
BMW	3 Series (E36)	93 - 95	1 or 2 airbags (ZAE, BAE)	YTD957
BMW	3 Series (E46)	98 - 05	MRS 3, MRS 4	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	MRS5	YTD960
BMW	3 Series (E90/E91/E92/E93)	06 - 03/07	ACSM	YTD960
BMW	5 Series (E34)	91 - 93	Driver Airbag (5WK4 060)	YTD957

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
BMW	5 series (E34)	93 - 95	1 or 2 airbags (ZAE, BAE)	YTD957
BMW	5 Series (E39)	96 - 04	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3, MRS 4	YTD957 or YTD951 A6 / YTD960
BMW	5 Series (E60/E61)	04 - 03/07	ACSM	YTD960
BMW	6 Series (E63/E64)	05 - 03/07	ACSM	YTD960
BMW	7 Series (E32)	91 - 93	Driver Airbag (5WK4 060)	YTD957
BMW	7 Series (E38)	94 - 02	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3, MRS 4	YTD957 or YTD951 A6 / YTD960
BMW	8 series (E31)	93 - 95	1 or 2 airbags (ZAE, BAE)	YTD957
BMW	8 Series (E31)	90 - 99	ZAE BAE, ZAE2, MRS 1, MRS 2	YTD957
BMW	X3 (E83)	03 -	MRS 4 Redesign	YTD951 A6 / YTD960
BMW	X5 (E53)	00 -	MRS 3, MRS 4	YTD951 A6 / YTD960
BMW	Z3 (E36)	96 - 03	MRS 3, MRS 4	YTD957 or YTD951 A6 / YTD960
BMW	Z4 (E85/E86)	06 -	ACSM	YTD951 A6 / YTD960
BMW	Z8 (E52)	00 - 03	MRS 3, MRS 4	YTD957 or YTD951 A6
Citroen	Berlingo	96 - 00	Airbag/ Seat Belt	YTD953 or YTD951 K2 or K9
Citroen	Berlingo	00 -	Autoliv ACU /TRW Airbag	YTD951 K2 or K9
Citroen	C2	03 -	Autoliv ACU	YTD951 K2 or K9
Citroen	C3	02 -	Temic SRS	YTD951 K2 or K9
Citroen	C4	04 -	Temic SRS	YTD951 K2 or K9
Citroen	C5	00 -	Temic SRS	YTD951 K2 or K9
Citroen	C8	02 -	Temic SRS	YTD951 K2 or K9
Citroen	Dispatch/Jumpy	95 - 00	Airbag / Seat Belt / Side Airbags	YTD953 or YTD951 K2 or K9
Citroen	Dispatch/Jumpy	00 -	Autoliv ACU	YTD951 K2 or K9
Citroen	Evasion	95 - 00	Airbag / Seat Belt / Side Airbags	YTD953 or YTD951 K2 or K9
Citroen	Evasion	00 -	Autoliv ACU	YTD951 K2 or K9
Citroen	Relay / Jumper	94 - 00	Breed SRS / Breed 97 MY / Siemens 99 MY	Use Fiat Ducato
Citroen	Saxo	96 - 00	Airbag / Seat Belt	YTD953 or YTD951 K2 or K9
Citroen	Saxo	00 - 03	Autoliv ACU	YTD951 K2 or K9
Citroen	Synergie	96 - 00	Airbag/ Seat Belt/ Side Airbags	YTD953 or YTD951 K2 or K9
Citroen	Synergie	00 - 03	Autoliv ACU	YTD951 K2 or K9
Citroen	Xantia	96 - 00	Airbag/ Seat Belt/ Side Airbags	YTD953 or YTD951 K2 or K9
Citroen	Xantia	00 - 02	Autoliv ACU	YTD951 K2 or K9
Citroen	XM	96 - 98	Airbag/ Seat Belt	YTD953 or YTD951 K2 or K9
Citroen	XM	00 - 01	Autoliv ACU	YTD951 K2 or K9
Citroen	Xsara	00 -	Autoliv ACU	YTD951 K2 or K9
Citroen	Xsara Picasso	00 -	Autoliv ACU	YTD951 K2 or K9
Fiat	Barchetta	96 - 98	TRW2 Airbag w/pretensioners	YTD958 or YTD951 D1
Fiat	Barchetta	97 - 00	TRW MY97	YTD958 or YTD951 D1
Fiat	Bravo/Brava	95 - 00	Breed	YTD958 or YTD951 D1
Fiat	Bravo/Brava	97 - 02	Breed MY97	YTD958 or YTD951 D1
Fiat	Coupe	94 - 02	TRW2 , TRW MY97	YTD958 or YTD951 D1
Fiat	Croma '05	05 -	TRW MY03	YTD950 or YTD959
Fiat	Doblo	00 - 05	Autoliv MY99	YTD951 D1
Fiat	Ducato	94 - 02	Breed Airbag w/pretensioners, Breed MY97, TRW MY99	YTD958 or YTD951 D1
Fiat	Ducato RST	01 -	Siemens MY99	YTD951 D1
Fiat	Idea	04 -	TRW MY03	YTD959

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Fiat	Marea/Weekend	96 - 02	Allied Signal, Allied MY97, Breed MY97	YTD958 or YTD951 D1
Fiat	Multipla	98 - 01	Breed 97	YTD958 or YTD951 D1
Fiat	Multipla	02 -	Siemens MY99	YTD951 D1
Fiat	Palio	97 - 01	TRW2, TRW MY97	YTD958 or YTD951 D1
Fiat	Palio RST	01 - 02	TRW MY97	YTD951 D1
Fiat	Palio RST 2	02 -	TRW MY97	YTD951 D1
Fiat	Panda 03	03 -	TRW MY99	YTD951 D1
Fiat	Punto	93 - 99	TRW2, TRW MY97	YTD958 or YTD951 D1
Fiat	Punto '99	99 - 03	TRW MY97	YTD958 or YTD951 D1
Fiat	Punto '03	03 - 05	TRW MY97, TRW MY99	YTD951 D1
Fiat	Scudo	96 - 04	Autoliv ACU, Autoliv Central Airbags	YTD953 or YTD951 K2 or K9
Fiat	Seicento	98 - 04	TRW MY97	YTD958 or YTD951 D1
Fiat	Stilo	01 - 05	Siemens MY99	YTD951 D1
Fiat	Ulysse	95 - 02	Autoliv Central Airbags, Autoliv side airbags	YTD953 or YTD951 K2 or K9
Fiat	Ulysse '02	02 - 05	Temic SRS	YTD953 or YTD951 K2 or K9
Ford	Cougar	99 - 02	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	Crown Victoria	96 - 98	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	Crown Victoria	98 - 07	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Crown Victoria	00 - 07	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Escort	95 - 02	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Expedition	97- 99	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	Expedition	99 - 08	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Explorer	96 - 06	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	Explorer	00 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Excursion	00 - 05	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Excursion	05 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	E-Series	97 - 05	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	E-Series	05 - 08	RCM - Restraint Control Module	YTD950 or YTD960
Ford	F-250 Light Duty	97 - 99	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	F-250 Light Duty	99 - 02	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Fiesta	99 -	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Fiesta	02 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Focus	99 -	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Focus	99 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Focus C-MAX	05 -	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Focus C-MAX	05 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	F-Series Super Duty	99 - 02	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	F-Series Super Duty	01 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	GT	05 - 06	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Fusion	02 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Ka	96 - 06	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Street Ka	03 -	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Maverick	01 - 04	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Maverick 05	05 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Mondeo III	01 - 06	RCM - Restraint Control Module	YTD950 or YTD960

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Ford	Ranger	06 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Transit	00 - 06	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Transit / Torneo Connect	02 -	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	WindStar	96 - 98	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	WindStar	99 - 04	RCM - Restraint Control Module	YTD950 or YTD960
GM	Agila	00 - 08	Agila SRS	YTD951 A2
GM	Astra F	94 - 98	Airbag S	YTD951 J7
GM	Astra-G	98 - 04	Airbag SAB6	YTD951 J7
GM	Astra-H	04 -	Astra-H SDM Airbag	YTD960
GM	Calibra	93 - 97	Airbag S	YTD951 J7
GM	Cavalier	93 - 95	Airbag S	YTD951 J7
GM	Combo	02 - 06	Airbag 20	YTD951 F2
GM	Corsa-B	94 - 01	Airbag S	YTD951 J7
GM	Corsa-B	94 - 01	Airbag SAB6	YTD951 J7
GM	Corsa-C	01 - 06	Airbag 20	YTD951 F2
GM	Corsa-D	06 -	Corsa-D SDM Airbag	YTD960
GM	Frontera-A	97 - 98	Airbag SDM (5V)	YTD951 G2
GM	Frontera-B	99 - 02	Airbag SDM (5V)	YTD951 G2
GM	Meriva	03 - 08	Airbag 20	YTD951 F2
GM	Monterey	97 - 98	Airbag SDM (5V)	YTD951 G2
GM	Omega-B	94 - 99	Airbag S	YTD951 J7
GM	Omega-B	94 - 01	Airbag SAB6	YTD951 J7
GM	Omega-B	01 - 03	Airbag 20	YTD951 F2
GM	Signum	01 -	Signum SDM Airbag	YTD960
GM	Speedster / VX220	01 - 06	Airbag	YTD951 J7
GM	Tigra-A	95 - 99	Airbag S	YTD951 J7
GM	Tigra-B	05 - 08	Airbag 20	YTD951 F2
GM	Vectra-A	93 - 95	Airbag S	YTD951 J7
GM	Vectra-B	95 - 01	Airbag SAB6	YTD951 J7
GM	Vectra-B	95 - 01	Airbag SAE4	YTD951 J7
GM	Vectra-B	95 - 01	Airbag	YTD951 J7
GM	Vectra-C	01 -	Vectra-C SDM Airbag	YTD960
GM	Vivaro	01 - 06	Airbag ACU3	YTD951 A2
GM	Zafira-A	99 - 05	Airbag SAB6	YTD951 J7
GM	Zafira-B	05 -	Zafira-B SDM Airbag	YTD960
Lancia	Kappa	94 - 01	TRW2 Airbag w/pretensioners, TRW MY97	YTD958 or YTD951 D1
Lancia	Lybra	99 - 06	Allied MY97, Siemens MY99	YTD958 or YTD951 D1
Lancia	Musa	04 - 06	TRW MY03	YTD959
Lancia	Phedra	02 - 06	Temic SRS	YTD953 or YTD951 K2 or K9
Lancia	Thesis	02 - 06	TRW MY99	YTD951 D1
Lancia	Y	96 - 03	Allied Signal, Allied MY97	YTD958 or YTD951 D1
Lancia	Ypsilon	03 - 06	Autoliv MY99	YTD951 D1
Lancia	Z	96 - 02	Autoliv, Autoliv ACU	YTD953 or YTD951 K2 or K9
Land Rover	Freelander	98 - 02	Autoliv AC4	YTD951 A1
Land Rover	Freelander	03 - 06	Siemens SRE Smart	YTD951 A1

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Land Rover	Discovery	96 - 98	TRW SPS	YTD951 L11
Land Rover	Discovery II	98 - 04	TRW Generation 4	YTD951 A1
Land Rover	Range Rover	97 - 02	TRW SPS	YTD951 L11
Land Rover	New Range Rover	03 -	Bosch MRS4	YTD951 F2
Mercedes	A Class (W168)	98 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	A Class (W169)	04 -	AB 169	YTD950
Mercedes	B Class (W245)	05 -	AB 169	YTD950
Mercedes	C Class (W202)	93 - 01	Fast Codes	YTD951 B2 or K2
Mercedes	C Class (W203)	00 - 09/03	Arminca	YTD951 B2 or K2
Mercedes	C Class (W203)	09/03 - 07	Armada	YTD950
Mercedes	C Class (W203)	09/03 - 07	WSS	YTD950
Mercedes	CL Class (W215)	99 - 09/02	Armin	YTD951 B2 or K2
Mercedes	CL Class (W215)	09/02 - 06	Armada 2	YTD950
Mercedes	CLK (W208)	93 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	CLK (W209)	02 - 04/04	Arminca	YTD950
Mercedes	CLK (W209)	04/04 - 02	Armada	YTD950
Mercedes	CLK (W209)	04/04 - 02	WSS	YTD950
Mercedes	CLS (W219)	04 -	Armada	YTD950
Mercedes	CLS (W219)	04 -	RGSL 211	YTD950
Mercedes	CLS (W219)	04 -	RGSR 211	YTD950
Mercedes	CLS (W219)	04 -	WSS	YTD950
Mercedes	E Class (W210)	95 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	E Class (W211)	02 -	Armada	YTD950
Mercedes	E Class (W211)	02 -	RGSL 211	YTD950
Mercedes	E Class (W211)	02 -	RGSR 211	YTD950
Mercedes	E Class (W211)	02 -	WSS	YTD950
Mercedes	G Class (W461)	98 - 02	Fast Codes	YTD951 B2 or K2
Mercedes	G Class (W463)	98 -	Fast Codes	YTD950
Mercedes	G Class (W463)	98 -	Armin	YTD950
Mercedes	M Class (W163)	93 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	M Class (W164)	05 -	Arcade 164	YTD950
Mercedes	M Class (W164)	05 -	RGSL 164	YTD950
Mercedes	M Class (W164)	05 -	RGSR 164	YTD950
Mercedes	M Class (W164)	05 -	WSS	YTD950
Mercedes	R Class (251)	05 -	Arcade 164	YTD950
Mercedes	R Class (251)	05 -	RGSL 164	YTD950
Mercedes	R Class (251)	05 -	RGSR 164	YTD950
Mercedes	R Class (251)	05 -	WSS	YTD950
Mercedes	S Class (W140)	91 - 08	Fast Codes	YTD951 B2 or K2
Mercedes	S Class (W220)	98 - 09/02	Fast Codes	YTD950
Mercedes	S Class (W220)	09/02 -	Armada 2	YTD950
Mercedes	S Class (W220)	09/02 -	REVASL	YTD950
Mercedes	S Class (W220)	09/02 -	REVASR	YTD950
Mercedes	S Class (W221)	05 -	Arcade 221	YTD950
Mercedes	S Class (W221)	05 -	RGSL 221	YTD950

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Mercedes	S Class (W221)	05 -	RGSR 221	YTD950
Mercedes	S Class (W221)	05 -	WSS 221	YTD950
Mercedes	SL (R129)	93 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	SL (R230)	03 - 06	Armada 2	YTD950
Mercedes	SLK (R170)	93 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	SLK (R171)	04 -	Armada	YTD950
Mercedes	SLR (199)	04 -	Armada 2	YTD950
Mercedes	Sprinter (W901 / W902 / W903 / W904)	95 - 02	Fast Codes	YTD951 B2 or K2 and YTD955
Mercedes	Vaneo (414)	02 -	Armin	YTD951 B2 or K2
Mercedes	Viano (639)	03 -	Armada	YTD951 B2 or K2
Mercedes	Vito (639)	03 -	Armada	YTD951 B2 or K2
MINI	MINI (R50 / R53)	00 - 07	MRS 4	YTD951 A6
Peugeot	1007	04 - 06	TRW Airbag	YTD951 K2 or K9
Peugeot	106	96 - 00	Airbag / Seat Belt	YTD953 or YTD951 K2 or K9
Peugeot	106	00 - 04	Autoliv ACU	YTD951 K2 or K9
Peugeot	206	98 - 00	Airbag / Seat Belt / Side Airbags	YTD953 or YTD951 K2 or K9
Peugeot	206	00 - 06	Autoliv ACU / Temic SRS	YTD951 K2 or K9
Peugeot	306	96 - 00	Airbag / Seat Belt / Side Airbags	YTD953 or YTD951 K2 or K9
Peugeot	306	00 - 02	Autoliv ACU	YTD951 K2 or K9
Peugeot	307	01 - 07	Temic SRS	YTD951 K2 or K9
Peugeot	406	95 - 00	Airbag/ Seat Belt/ Side Airbags	YTD953 or YTD951 K2 or K9
Peugeot	406	00 - 03	Autoliv ACU	YTD951 K2 or K9
Peugeot	407	05 -	Temic SRS	YTD951 K2 or K9
Peugeot	605	97 - 00	Airbag/ Seat Belt/ Side Airbags	YTD953 or YTD951 K2 or K9
Peugeot	607	01 - 06	Temic SRS	YTD951 K2 or K9
Peugeot	806	96 - 00	Airbag/ Seat Belt/ Side Airbags	YTD953 or YTD951 K2 or K9
Peugeot	806	00 - 03	Autoliv ACU	YTD951 K2 or K9
Peugeot	807	02 -	Temic SRS	YTD951 K2 or K9
Peugeot	Boxer	96 - 00	Breed SRS / Breed 97 MY / Siemens 99 MY	Use Fiat Ducato
Peugeot	Expert	97 - 00	Airbag/ Seat Belt	YTD953 or YTD951 K2 or K9
Peugeot	Expert	00 -	Autoliv ACU	YTD951 K2 or K9
Peugeot	Partner/Ranch	96 - 00	Airbag/ Seat Belt	YTD953 or YTD951 K2 or K9
Peugeot	Partner/Ranch	00 -	Autoliv ACU / TRW Airbag	YTD951 K2 or K9
Renault	Clio II	98 - 06	AB7	YTD951 A1
Renault	Clio II	98 - 06	AB8	YTD951 A1
Renault	Clio III	06 -	AB9	YTD950
Renault	Laguna	93 - 00	AC6	YTD951 A1
Renault	Laguna	93 - 00	AC6 Phase 2	YTD951 A1
Renault	Laguna	93 - 00	EC5	YTD951 A1
Renault	Megane	95 - 02	AC4	YTD951 A1
Renault	Megane	95 - 02	AC4 Phase 2	YTD951 A1
Renault	Megane	95 - 02	AC6	YTD951 A1
Renault	Megane	95 - 02	AC6 Phase 2	YTD951 A1
Renault	Megane	95 - 02	ACU 3.8	YTD951 A1
Renault	Megane II	02 -	Siemens Autoliv ACU4 MK2	YTD950

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Renault	Modus	04 -	AB9	YTD950
Renault	Scenic	95 - 02	EC5	YTD951 A1
Renault	Scenic	95 - 02	AC4	YTD951 A1
Renault	Scenic	95 - 02	AC4 Phase 2	YTD951 A1
Renault	Scenic	95 - 02	AC6	YTD951 A1
Renault	Scenic	95 - 02	AC6 Phase 2	YTD951 A1
Renault	Scenic	95 - 02	EC5	YTD951 A1
Renault	Scenic II	03 -	Siemens Autoliv ACU4 MK2	YTD950
Seat	Alhambra	96 -	KWP1281 / KW2000	YTD951 A1
Seat	Altea	04 -	CAN	YTD950
Seat	Arosa	97 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Cordoba	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Ibiza	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Leon	00 - 04	KWP1281 / KW2000	YTD951 A1
Seat	Leon	04 -	CAN	YTD950
Seat	Toledo	92 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Toledo III	04 -	CAN	YTD950
Skoda	Fabia	00 - 07	KWP1281 / KW2000	YTD951 A1
Skoda	Fabia II	07 -	CAN	YTD950
Skoda	Felicia	95 - 04	KWP1281 / KW2000	YTD951 A1
Skoda	Octavia	96 - 04	KWP1281 / KW2000	YTD951 A1
Skoda	Octavia II	04 -	CAN	YTD950
Skoda	Superb	02 - 04	KWP1281 / KW2000	YTD951 A1
VW	Beetle	99 -	KWP1281 / KW2000	YTD951 A1
VW	Bora	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Bora	05 -	CAN	YTD950
VW	Cabrio	95 - 02	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	92 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	05 -	CAN	YTD950
VW	Corrado	91 - 95	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	EOS	05 -	CAN	YTD950
VW	Eurovan	99 - 03	KWP1281 / KW2000	YTD950
VW	Golf/GTI	91 - 03	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Golf/GTI	03 -	CAN	YTD950
VW	Golf Plus	05 -	CAN	YTD950
VW	Jetta	93 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Jetta	05 -	CAN	YTD950
VW	Lupo	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	94 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	05 -	CAN	YTD950
VW	Phaeton	03 -	KWP1281 / KW2000	YTD951 A1
VW	Polo	98 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Touareg	03 - 06	KWP1281 / KW2000	YTD951 A1
VW	Touareg	07 -	CAN	YTD950
VW	Touran	03 -	CAN	YTD950

**FASTCHECK AIRBAG**

Make	Model	From/To	System	Harness Required
VW	Sharan	95 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle T5	04 -	CAN	YTD950
VW	Vento	92 - 98	KWP1281 / KW2000	YTD950

FASTCHECK CLIMATE CONTROL

Make	Model	From/To	System	Harness Required
Alfa Romeo	147	00 - 07	Delphi (Single Zone) Delphi (Dual Zone)	YTD959
Alfa Romeo	156	97 - 02	Harrison Climate Control	YTD951 G1
Alfa Romeo	159	05 -	Delphi (Single Zone) Delphi (Dual Zone)	YTD950 or YTD959
Alfa Romeo	GT	04 -	Delphi (Single Zone) Delphi (Dual Zone)	YTD959
Alfa Romeo	GTV	98 - 03	Harrison Climate Control	YTD951 G1
Alfa Romeo	Spider	98 - 03	Harrison Climate Control	YTD951 G1
Audi	80/Cabrio/Coupe/Quattro	94 - 96	KWP1281	YTD952
Audi	A2	00 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	96 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	04 -	CAN	YTD950
Audi	A4	95 - 04	KWP1281/KW2000	YTD951 A1
Audi	A4	04 -	CAN	YTD950
Audi	S4	92 - 02	KWP1281/KW2000	YTD952
Audi	S4	04 -	CAN	YTD950
Audi	A6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	A6	04 -	CAN	YTD950
Audi	S6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S6	04 -	CAN	YTD950
Audi	Allroad Quattro	01 - 04	KWP1281/KW2000	YTD951 A1
Audi	Q7	06 -	CAN	YTD950
Audi	A8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	A8	04 -	CAN	YTD950
Audi	S8	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S8	04 -	CAN	YTD950
Audi	TT	98 - 07	KWP1281/KW2000	YTD951 A1
Audi	TT	07 -	CAN	YTD950
Audi	100	94 - 97	KWP1281/KW2000	YTD952
BMW	1 Series (E81/E87)	04 - 03/07	IHR E87/E90 / IHKR E87/E90 / IHKA E87	YTD960
BMW	3 Series (E36)	90 - 98	IHKA E36	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E46)	98 - 05	IHKR E46 / E83, IHKA E46 / E83	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	IHR E87/E90 / IHKR E87/E90 / IHKA E87/E90	YTD960
BMW	5 Series (E39)	96 - 04	IHR E39, IHKR E39 / E53, IHKA E39 / E53, IHKA E39	YTD957 or YTD951 A6 / YTD960
BMW	5 Series (E60/E61)	04 - 03/07	IHKA E60/E63/E65	YTD960
BMW	6 Series (E63/E64)	05 - 03/07	IHKA E60/E63/E65	YTD960
BMW	7 Series (E38)	94 - 02	IHKR E38, IHKA E38, FGB E38, FHK E38	YTD957 or YTD951 A6 / YTD960
BMW	7 Series (E65)	02 - 03/07	IHKA E60/E63/E65	YTD960
BMW	X3 (E83)	03 -	IHKR E46 / E83, IHKA E46 / E83	YTD951 A6 / YTD960
BMW	X5 (E53)	00 -	IHKR E39 / E53, IHKA E39 / E53	YTD951 A6 / YTD960
BMW	Z3 (E36)	96 - 03	IHKA E36	YTD957 or YTD951 A6 / YTD960
BMW	Z4 (E85)	03 -	IHS/IHKS E85, IHKA E85	YTD951 A6 / YTD960
BMW	Z8 (E52)	00 - 03	IHKS E52	YTD957 or YTD951 A6 / YTD960
Citroen	C3	00 -	Behr	YTD951 I2
Citroen	C5	99 -	Valeo	YTD951 I2
Citroen	Xantia	99 -	Valeo	YTD951 I2
Citroen	Xsara	00 -	Behr	YTD951 I2

FASTCHECK CLIMATE CONTROL

Make	Model	From/To	System	Harness Required
Fiat	Croma 05	05 -	Valeo Climate Control (Two Zone)	YTD950 or YTD959
Fiat	Idea	04 -	Denso Climate Control 1 (Two Zone)	YTD959
Fiat	Panda 03	03 - 05	Denso Climate Control 1 (Single Zone)	YTD959
Fiat	Punto 03	03 - 05	Denso 2 Climate Control (Two Zone)	YTD959
Fiat	Ulysse	95 - 02	Behr Climate Control	YTD951 I2
Ford	Crown Victoria	95 - 07	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Expedition	99 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Expedition	99 -	RCC - Remote Climate Control	YTD950 or YTD960
Ford	Explorer	94 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Fiesta	06 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Focus	02 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Focus C-MAX	06 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Fusion	02 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Galaxy	99 - 06	RCC - Remote Climate Control	YTD950 or YTD960
Ford	Mondeo	01 - 06	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
GM	Astra-G	02 - 04		YTD951 J2
GM	Astra-H	04 -	ECC/SAC	YTD960
GM	Corsa-C	03 - 06		YTD951 J2
GM	Corsa-D	06 -	ECC/SAC	YTD960
GM	Corsa-D	06 -	HVA	YTD960
GM	Meriva	03 - 08		YTD951 J2
GM	Omega-B	94 - 99		YTD951 J2
GM	Omega-B	00 - 03		YTD951 J2
GM	Signum	01 -	ECC/SAC	YTD960
GM	Signum	01 -	HVA	YTD960
GM	Vectra-B	95 - 01		YTD951 J2
GM	Vectra-C	01 -	ECC/SAC	YTD960
GM	Vectra-C	01 -	HVA	YTD960
GM	Zafira-A	03 - 05		YTD951 J2
GM	Zafira-B	05 -	ECC/SAC	YTD960
Lancia	Musa	04 -	Denso 1 Climate Control (Two Zone)	YTD959
Lancia	Thesis	02 - 06	Borletti / Hella Climate Control	YTD959
Lancia	Ypsilon	03 - 06	Denso Climate Control (Two Zone)	YTD959
Lancia	Z	96 - 02	Behr Climate Control	YTD951 I2
Land Rover	Range Rover	97 - 02	Hevac	YTD951 A1
Land Rover	New Range Rover	03 -	Hevac	YTD951 F2
Mercedes	A Class (W168)	98 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	A Class (W169)	04 -	KLA 169	YTD950
Mercedes	B Class (W245)	05 -	KLA 169	YTD950
Mercedes	C Class (W202)	93 - 01	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	C Class (W203)	00 - 09/03	KLA203	YTD951 B2/C2/J2 and/or YTD956
Mercedes	C Class (W203)	09/03 - 07	KLA203 (CAN)	YTD950
Mercedes	C Class (W203)	09/03 - 07	STH 211	YTD950
Mercedes	CL Class (W215)	99 - 06	KLA220	YTD951 B2/C2/J2 and/or YTD956
Mercedes	CL Class (W215)	09/02 - 06	STH 220	YTD950

FASTCHECK CLIMATE CONTROL

Make	Model	From/To	System	Harness Required
Mercedes	CLK (W208)	98 - 02	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	CLK (W209)	02 -	KLA203	YTD951 B2/C2/J2 and/or YTD956
Mercedes	CLK (W209)	04/04 - 02	KLA203 (CAN)	YTD950
Mercedes	CLK (W209)	04/04 - 02	STH 211	YTD950
Mercedes	CLS (W219)	04 -	KLA 211	YTD950
Mercedes	CLS (W219)	04 -	STH 211	YTD950
Mercedes	E Class (W210)	95 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	E Class (W211)	02 -	KLA 211	YTD950
Mercedes	E Class (W211)	02 -	LRK 211	YTD950
Mercedes	E Class (W211)	02 -	STH 211	YTD950
Mercedes	G Class (W461)	98 - 02	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	G Class (W463)	98 - 04/04	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	G Class (W463)	04/04 -	KLA203 (CAN)	YTD950
Mercedes	G Class (W463)	04/04 -	STH 203	YTD950
Mercedes	M Class (W164)	05 -	KLA 164	YTD950
Mercedes	M Class (W164)	05 -	STH 164	YTD950
Mercedes	R Class (251)	05 -	KLA 164	YTD950
Mercedes	R Class (251)	05 -	STH 164	YTD950
Mercedes	S Class (W140)	95 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	S Class (W220)	99 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	S Class (W220)	09/02 -	STH 220	YTD950
Mercedes	S Class (W221)	05 -	KLA 221	YTD950
Mercedes	S Class (W221)	05 -	HVCR 221	YTD950
Mercedes	S Class (W221)	05 -	STH 221	YTD950
Mercedes	SL Class (R129)	95 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	SL (R230)	03 - 06	KLA230	YTD951 B2/C2/J2 and/or YTD956
Mercedes	SLK (R170)	98 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	SLK (R171)	04 -	KLA 171	YTD950
Mercedes	SLR (199)	04 -	KLA230	YTD951 B2/C2/J2 and/or YTD956
Mercedes	Sprinter (W901 / W902 / W903 / W904)	95 - 02	KLA	YTD951 B2/C2/J2 and/or YTD956
MINI	MINI (R50 / R53)	00 - 07	MINI IHKA	YTD951 A6
Peugeot	206	00 -	Behr GKR	YTD951 E2
Peugeot	307	00 -	Behr	YTD951 I2
Peugeot	406	99 - 04	Valeo	YTD951 I2
Peugeot	607	99 -	Valeo	YTD951 I2
Renault	Laguna I	98 - 99	BEHR	YTD951 A1
Renault	Laguna II	99 - 05	Valeo 4	YTD951 A1
Renault	Laguna II	99 - 05	Valeo 5	YTD951 A1
Renault	Megane	00 - 03	J64	YTD951 A1
Renault	Megane II	03 -	Controlled AC	YTD950
Renault	Scenic	00 - 03	J64	YTD951 A1
Renault	Scenic II	03 -	Controlled AC	YTD950
Seat	Alhambra	96 -	KWP1281 / KW2000	YTD951 A1
Seat	Altea	04 -	CAN	YTD950
Seat	Arosa	97 - 05	KWP1281 / KW2000	YTD951 A1

FASTCHECK CLIMATE CONTROL

Make	Model	From/To	System	Harness Required
Seat	Cordoba	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Ibiza	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Leon	00 - 04	KWP1281 / KW2000	YTD951 A1
Seat	Leon	04 -	CAN	YTD950
Seat	Toledo	92 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Toledo III	04 -	CAN	YTD950
Skoda	Fabia	00 - 07	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Fabia II	07 -	CAN	YTD950
Skoda	Octavia	96 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Octavia II	04 -	CAN	YTD950
Skoda	Superb	02 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Beetle	99 -	KWP1281 / KW2000	YTD951 A1
VW	Bora	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Bora	05 -	CAN	YTD950
VW	Cabrio	95 - 02	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	92 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	05 -	CAN	YTD950
VW	Corrado	91 - 95	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	EOS	05 -	CAN	YTD950
VW	Eurovan	99 - 03	KWP1281 / KW2000	YTD950
VW	Golf/GTI	92 - 03	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Golf/GTI	03 -	CAN	YTD950
VW	Golf Plus	05 -	CAN	YTD950
VW	Jetta	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Jetta	05 -	CAN	YTD950
VW	Lupo	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	94 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	05 -	CAN	YTD950
VW	Phaeton	03 -	KWP1281 / KW2000	YTD951 A1
VW	Polo	98 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Touareg	03 - 06	KWP1281 / KW2000	YTD951 A1
VW	Touareg	07 -	CAN	YTD950
VW	Touran	03 -	CAN	YTD950
VW	Sharan	95 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle T5	04 -	CAN	YTD950
VW	Vento	92 - 98	KWP1281 / KW2000	YTD950

FASTCHECK EPB - Electronic Parking Brake

Make	Model	From/To	System	Harness Required
Audi	A6	04 -	EPB	YTD950
Audi	S6	04 -	EPB	YTD950
Audi	A8	04 -	EPB	YTD950
Ford	C-Max	03 -	EPB	YTD950
Ford	S-Max	06 -	EPB	YTD950
Ford	Transit	01 - 05	EPB	YTD950
Mercedes	CLS (W219)	04 -	SBC (CAN)	YTD950
Mercedes	E Class (W211)	02 -	Sensotronic BC	YTD951 G2
Mercedes	E Class (W211)	02 -	SBC (CAN)	YTD950
Mercedes	SL (R230)	03 - 06	Sensotronic BC	YTD951 G2 and/or YTD956
Mercedes	SL (R230)	03 - 06	SBC (CAN)	YTD950
Mercedes	SLR (199)	04 -	Sensotronic BC	YTD951 G2
Renault	Megane II	03 -	EPB	YTD950
Renault	Scenic II	02 -	EPB	YTD950
Renault	Espace IV	02 -	EPB	YTD950
Renault	Vel Satis	01 -	EPB	YTD950
VW	Passat	05 -	EPB	YTD950

FASTCHECK SERVICE

Make	Model	From/To	System	Harness Required
Alfa Romeo	147 (Mannesman VDO instrument panel)	00 - 07		YTD959
Alfa Romeo	159 (Siemens 2 Instrument panel)	05 -		YTD950 or YTD959
Alfa Romeo	GT (Mannesman VDO instrument panel)	04 -		YTD959
Audi	80/Cabrio/Coupe/Quattro	94 - 96	KWP1281	YTD952
Audi	A2	00 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	96 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	04 -	CAN	YTD950
Audi	A4	95 - 04	KWP1281/KW2000	YTD951 A1
Audi	A4	04 -	CAN	YTD950
Audi	S4	92 - 02	KWP1281/KW2000	YTD952
Audi	S4	04 -	CAN	YTD950
Audi	A6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	A6	04 -	CAN	YTD950
Audi	S6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S6	04 -	CAN	YTD950
Audi	Allroad Quattro	01 - 04	KWP1281/KW2000	YTD951 A1
Audi	Q7	06 -	CAN	YTD950
Audi	A8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	A8	04 -	CAN	YTD950
Audi	S8	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S8	04 -	CAN	YTD950
Audi	TT	00 - 07	KWP1281/KW2000	YTD951 A1
Audi	TT	07 -	CAN	YTD950
Audi	100	94 - 97	KWP1281/KW2000	YTD952
BMW	1 Series (E81/E87)	04 - 03/07	CBS	YTD960
BMW	1 Series (E81/E87)	04 - 03/07	Annual distance	YTD960
BMW	1 Series (E81/E87)	04 - 03/07	Battery change	YTD960
BMW	3 Series (E30)	88 - 91	Analogue	YTD957
BMW	3 Series (E36)	91 - 99	Analogue	YTD957 or YTD951 A2/F2
BMW	3 Series (E46)	98 - 05	Digital or Analogue	YTD957 or YTD951 A2/F2
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	CBS	YTD960
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	Annual distance	YTD960
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	Battery change	YTD960
BMW	5 Series (E34)	88 - 97	Analogue	YTD957
BMW	5 Series (E39)	97 - 03	Digital or Analogue	YTD957 or YTD951 A2/F2
BMW	5 Series (E60/E61)	04 - 03/07	CBS	YTD960
BMW	5 Series (E60/E61)	04 - 03/07	Annual distance	YTD960
BMW	5 Series (E60/E61)	04 - 03/07	Battery change	YTD960
BMW	6 Series (E63/E64)	05 - 03/07	CBS	YTD960
BMW	6 Series (E63/E64)	05 - 03/07	Annual distance	YTD960
BMW	6 Series (E63/E64)	05 - 03/07	Battery change	YTD960
BMW	7 Series (E38)	95 - 02	Digital or Analogue	YTD957 or YTD951 A2/F2
BMW	7 Series (E65)	02 - 03/07	CBS	YTD960
BMW	7 Series (E65)	02 - 03/07	Annual distance	YTD960
BMW	7 Series (E65)	02 - 03/07	Battery change	YTD960

FASTCHECK SERVICE

Make	Model	From/To	System	Harness Required
BMW	8 Series (E31)	91 - 97	Analogue	YTD957 or YTD951 A2/F2
BMW	X3 (E83)	03 -	Digital	YTD951 A2/F2
BMW	X5 (E53)	00 -	Digital or Analogue	YTD957 or YTD951 A2/F2
BMW	Z3 (E36)	96 - 02	Digital or Analogue	YTD957 or YTD951 A2/F2
BMW	Z4 (E85)	03 -	Digital	YTD951 A2/F2
BMW	Z8 (E52)	99 - 04	Analogue	YTD957
Fiat	Croma 05 (Marelli 2)	05 -		YTD950 or YTD959
Fiat	Idea (Marelli instrument panel - comfort)	04 -		YTD959
Fiat	Palio RST2 (Marelli instrument panel - Palio RST2)	02 -		YTD959
Fiat	Panda 03 (Marelli instrument panel)	03 -		YTD959
Fiat	Punto 03 (Marelli instrument panel - comfort)	03 - 05		YTD959
Fiat	Stilo (Visteon instrument panel)	01 -		YTD959
Ford	Galaxy (with VW engine)	95 - 00		YTD951 A1
GM	Agila	00 - 08	InstAgil	YTD951 J2
GM	Astra-G	98 - 04	Instr30	YTD951 J2
GM	Astra-H	04 -	CAN IPC	YTD960
GM	Corsa-C	01 - 06	Instr43	YTD951 J2
GM	Corsa-D	06 -	CAN IPC	YTD960
GM	Meriva	03 - 08	Instr43	YTD951 J2
GM	Signum	01 -	CAN IPC	YTD960
GM	Signum	01 -	Long-Life Oil Reset	YTD950 or YTD960
GM	Tigra-B	05 - 08	Instr43	YTD951 J2
GM	Vectra-C	01 -	CAN IPC	YTD960
GM	Vectra-C	01 -	Long-Life Oil Reset	YTD950 or YTD960
GM	Zafira-A	98 - 05	Instr30	YTD951 J2
GM	Zafira-B	05 -	CAN IPC	YTD951 J2
Lancia	Musa (Marelli instrument panel - comfort)	04 -		YTD959
Lancia	Thesis (Nippon Seiki instrument panel)	02 -		YTD959
Lancia	Ypsilon (Siemens instrument panel)	03 -		YTD959
Mercedes	A Class (W169)	04 -	Assyst Plus	YTD950
Mercedes	B Class (W245)	05 -	Assyst Plus	YTD950
Mercedes	C Class (W202)	96 - 00	FSS	YTD951 C2 and YTD956
Mercedes	C Class (W203)	00 - 03	FSS	YTD951 B2
Mercedes	CL (W215)	99 - 00	FSS	YTD951 C2 and YTD956
Mercedes	CL (W215)	00 - 05	FSS	YTD951 B2/C2
Mercedes	CLK (W208)	98 - 04	FSS	YTD951 C2 and YTD956
Mercedes	CLS (W219)	04 -	Assyst Plus	YTD950
Mercedes	E Class (W210)	96 - 02	FSS	YTD951 C2 and YTD956
Mercedes	E Class (W211)	02 -	Assyst Plus	YTD950
Mercedes	ML (W163)	97 - 05	FSS	YTD951 C2
Mercedes	ML (W164)	05 -	Assyst Plus	YTD950
Mercedes	R Class (V251)	05 -	Assyst Plus	YTD950
Mercedes	S Class (W140)	97 - 99	FSS	YTD951 C2 and YTD956
Mercedes	S Class (W220)	99 - 05	FSS	YTD951 B2/C2
Mercedes	S Class (W221)	05 -	Assyst Plus	YTD950



FASTCHECK SERVICE

Make	Model	From/To	System	Harness Required
Mercedes	SL (R129)	95 - 02	FSS	YTD951 C2/J2 and YTD956
Mercedes	SL (R230)	01 - 03	FSS	YTD951 C2/J2
Mercedes	SLK (R170)	98 - 01	FSS	YTD951 C2/J2 (and YTD956 if no J1962)
Mercedes	SLK (R171)	04 -	Assyst Plus	YTD950
Mercedes	Sprinter (W901 / W902 / W903 / W904)	95 - 02	FSS	YTD951 C2/J2 (and YTD955 if no J1962)
MG Rover	75	99 - 02		YTD951 F6 or F2
MINI	MINI (R50 / R53)	00 - 07		YTD951 F2
Saab	9-3	98 - 02		YTD951 A1
Saab	9-5	97 - 02		YTD951 A1
Seat	Alhambra	96 -	KWP1281 / KW2000	YTD951 A1
Seat	Altea	04 -	CAN	YTD950
Seat	Arosa	97 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Cordoba	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Ibiza	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Leon	00 - 04	KWP1281 / KW2000	YTD951 A1
Seat	Leon	04 -	CAN	YTD950
Seat	Toledo	92 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Toledo III	04 -	CAN	YTD950
Skoda	Fabia	00 - 07	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Fabia II	07 -	CAN	YTD950
Skoda	Octavia	96 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Octavia II	04 -	CAN	YTD950
Skoda	Superb	02 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Beetle	99 -	KWP1281 / KW2000	YTD951 A1
VW	Bora	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Bora	05 -	CAN	YTD950
VW	Cabrio	95 - 02	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	92 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	05 -	CAN	YTD950
VW	Corrado	91 - 95	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	EOS	05 -	CAN	YTD950
VW	Eurovan	99 - 03	KWP1281 / KW2000	YTD950
VW	Golf/GTI	92 - 03	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Golf/GTI	03 -	CAN	YTD950
VW	Golf Plus	05 -	CAN	YTD950
VW	Jetta	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Jetta	05 -	CAN	YTD950
VW	Lupo	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	94 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	05 -	CAN	YTD950
VW	Phaeton	03 -	KWP1281 / KW2000	YTD951 A1
VW	Polo	98 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Touareg	03 - 06	KWP1281 / KW2000	YTD951 A1
VW	Touareg	07 -	CAN	YTD950
VW	Touran	03 -	CAN	YTD950

Due to model changes, dates may not be precise. Try other leads or systems before contacting product support.
 Petrol vehicles MY2000 on (diesel MY2004 on) should be OBD II compliant and can be diagnosed via EOBD for emissions data.


FASTCHECK SERVICE

Make	Model	From/To	System	Harness Required
VW	Sharan	95 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle T5	04 -	CAN	YTD950
VW	Vento	92 - 98	KWP1281 / KW2000	YTD950
Volvo	850	93 - 97		YTD951 A1 or YTD954
Volvo	S40	97 - 98		YTD951 A1
Volvo	V40	97 - 98		YTD951 A1
Volvo	S70	97 - 98		YTD951 A1
Volvo	V70	97 - 98		YTD951 A1

*NOTE: The CAN variable service reset will only work with the EOBD harness YTD950, the switchable harness YTD951 should not be used.